



CMYK



Yellow: PANTONE 7409 C



Blue: PANTONE 285 C



Dieline: 100% Magenta

160mm

167mm

12mm


77mm

34mm

328mm

HOW TO USE:

- 1) Remove key from slot on side of station.
- 2) Place key in keyhole and turn 45°. Note there is an arrow on the key that will line up with the arrow on the box when the box is unlocked.



- 3) Place 1 - 3 bait blocks inside the station and fix to wire.
- 4) Close station, ensuring the lid is locked in place.
- 5) Inspect baits at least every 7 days.
- 6) Replace baits as necessary. It may take up to 2 weeks to control a significant rodent problem.

KIWICARE

NO RATS[®] BAIT STATION[™]

LOCKABLE AND REUSABLE



CAUTION: Keep out of reach of children



← TEAR HERE

NO RATS[®] BAIT STATION[™]

- Protects pets and children from access to bait.
- Protects bait from moisture and contamination.
- Can be used indoors and outdoors.

FOR BEST RESULTS:

- Eliminate as many alternative food sources as possible.
- Human odours may deter rats; wear gloves when handling station and/or bait.
- Place bait stations under cover, along walls or rafters and in dark sheltered areas where there are signs of rodent activity.
- Inspect bait at least every 7 days.
- For effective control continue to replace eaten bait until feeding ceases. Once rodent activity has ceased ensure untaken baits are removed and safely disposed of.
- For rats - Use 1 to 3 blocks in Kiwicare NO Rats Bait Stations, 10 m apart, or 5 m apart for high infestations.
- Refer to baiting products label for safe handling and use.

As Kiwicare Corporation Limited has no control over the storage or use of this product, no liability is accepted for accidents or damage arising from the incorrect storage or use of this product.

Kiwicare Corporation Limited
225 Maces Road, Christchurch,
New Zealand
Ph: +64 3 389 0778



*See kiwicare.co.nz for terms and conditions.